

Installation

The LX350 is only work on standard analog phones. Do not install the dialer on digital type telephones. The LX350 is telephone line powered and has non-volatile memory so it will not lose its program when unplugged from the telephone line.

Program register quick reference

Register	Register description	Valid entries	Default data
01	Hotline dial number	1234567890*,#1,#2	empty
11	Pulse digit handler	0-3	0
12	Off hook dial delay in milliseconds	1-3000	750
13	Restrict calls	0-1	0
14	DTMF on time in milliseconds	50-500	100
15	DTMF off time in milliseconds	50-500	100
16	On hook timing in milliseconds	150-1000	800
17	Off hook timing in milliseconds	100-2000	100
70	Program password	12345678908*,#1	#0*
88	Restore default settings		
99	Exit programming		

Entering program mode

Lift the telephone handset dial the default programming password #0*, you will hear one beep. You are now in program mode and can enter any valid program register. If you enter the password incorrectly you will have to hang the phone up for the amount of time programmed in register 16 then lift the handset again and enter the program password again. To exit program mode dial 99 wait for beep and hang up. If you have previously programmed the dialer to dial when the handset is lifted you will have to wait for it to finish dialing before entering program mode. At any time you here 4 beeps this means a program entry was incorrect.

Programming semantics

When programming the dialer use the following semantics: First you have to be in program, this is explained in section “*Entering program mode*”.

1. *Dial register number and you will hear 1 beep .*
2. *Dial program data.*
3. *Dial ## to save register entry and you will hear 2 beeps.*

Example: 01 beep 12086391595 ## beep beep. This programs the hotline dial number with 12086391595.

Special character entries for dial out registers

#1 = #

#2 = 500ms pause.

In the following registers you can use the all of the above special character entries:

01

Register 01 Hotline dial number

When this register is programmed with a number the dialer will dial it automatically when the telephone handset is taken off hook.

Scenario: You want the dialer to dial 208-639-1595 when the phone goes off hook.

How to:

1. 01 beep
2. 2086391595
3. ## beep beep

Scenario: You want to remove the hotline number you just put in.

How to:

1. 01 beep
2. ## beep beep

Register 11 Pulse digit handler

With this register you can tell the dialer how to handle pulse digits when received.

Valid Entries:

- 0 = Process normally
- 1 = Ignore
- 2 = Restrict
- 3 = Dial out again as DTMF

Scenario: You want to use the dialer as a pulse to tone convertor.

How to:

1. 11 beep
2. 3
3. ## beep beep

Register 12 Off hook dial delay in milliseconds

This register comes into play when using the Hotline dial feature. This register determines the delay from when the phone goes off hook to when it dials the hotline number.

Scenario: You want the dialer to delay 2000 milliseconds (2 seconds) before dialing hotline number.

How to:

1. 12 beep
2. 2000
3. ## beep beep

Register 13 Call Restrict Mode

With this register you can instruct the dialer to restrict all outgoing calls.

Valid Entries:

- 0 = Allow outgoing calls
- 1 = Restrict outgoing calls

Scenario: You want the dialer to restrict all calls.

How to:

1. 13 beep
2. 1
3. ## beep beep

Register 14 Dtmf on time in milliseconds

This sets the duration of the dtmf tone of each digit the dialer dials.

Scenario: You want the dtmf tone on time to be 50 milliseconds.

How to:

1. 14 beep
2. 50
3. ## beep beep

Register 15 Dtmf off time in milliseconds

This sets the duration of the silence period between each dtmf tone the dialer dials.

Scenario: You want the dtmf tone off time to be 50 milliseconds.

How to:

1. 15 beep
2. 50
3. ## beep beep

Register 16 On hook timing in milliseconds

When the telephone receiver is placed on hook the dialer waits this amount of time before resetting for a new call.

Scenario: You want the on hook time to be 1000 milliseconds (1 second)

How to:

1. 16 beep
2. 1000
3. ## beep beep

Register 17 Off hook timing in milliseconds

When the telephone receiver is lifted off hook the dialer waits this amount of time before acknowledging a valid off hook.

Scenario: You want the off hook time to be 100 milliseconds.

How to:

1. 17 beep
2. 100
3. ## beep beep

Register 70 program password

With this register you can change the default program password.

Scenario: You want to change the password to 5*78*

How to:

1. 70 beep
2. 5*78*
3. ## beep beep

Register 88 Restore default settings

With this register you can reload the dialer default settings. Important: After you enter 88## you must wait for the 2 confirmation beeps. Do not hang up before hearing the 2 confirmation beeps, doing so may corrupt the dialer database.

How to:

1. 88 beep
2. ## beep beep

Register 99 Exit programming

Dialing this register will exit programming mode no ## needed.